## SIMS GO WI-FI INSTALL ATION PROCEDURE

### To install the SIMS™ GO update on your Floormap®X Tablet via Wi-Fi:

Important: Ensure the FloormapX is fully assembled, including all cable connections between scanner head, mainframe and tablet.

- 1. Power on the FloormapX and the tablet computer.
- 2. Enable Wi-Fi through your preference system menu.
- 3. Select a network and get connected.
- 4. Follow the steps on your screen to install the software.

## **SIMS GO USB INSTALLATION PROCEDURE**

#### To install the SIMS GO update on your FloormapX Tablet via USB key:

- 1. Download the compressed software file from <a href="https://www.eddyfi.com/en/software/floormapx-software">https://www.eddyfi.com/en/software/floormapx-software</a>
- 2. Decompress the file.
- 3. Copy the 1.1R2\_SIMSGO.FloormapUpdate file to a USB key.

Important: Ensure the FloormapX is fully assembled, including all cable connections between scanner head, mainframe and tablet.

- 4. Connect the USB key to the tablet computer.
- 5. Power on your FloormapX and tablet computer.
- 6. When prompted to proceed with the update, tap Yes
- 7. Wait some time for the software install option to become available (the software version to update will be 'greyed out' until the system is powered up and a connection between the component parts is established).
- 8. Tap on the version to update, and then tap Yes.
- 9. The software is updated and the FloormapX restarts automatically.
- 10. Remove the USB key from the FloormapX tablet.

#### Note:

If your USB key is still connected to the instrument when it restarts, the system will attempt to update the software again. Ignore this message. You will need to remove the 1.1R2\_SIMSGO.FloormapUpdate file from your USB to avoid seeing the software update message every time you connect your USB key to the FloormapX tablet.

# SIMS PRO PC INSTALLATION PROCEDURE

- 1. Download the compressed software file from <a href="https://www.eddyfi.com/en/software/floormapx-software">https://www.eddyfi.com/en/software/floormapx-software</a>
- 2. Decompress the file.
- 3. Double-click on the file and follow the instructions on your screen to complete the installation.

