

# ICON™ 4.6.1 Release Notes

### **New Features**

- Configuration management is now available from within ICON:
  - o Switch the active configuration without restarting the application
  - o Add, rename, copy, and remove configurations.
  - o Manage multiple copies of the same configuration.
- New overlay template manager functionality:
  - o Templates now can contain annotations with data from multiple sensors
  - o Annotations can be placed anywhere within the template and resized
  - o Annotation options now include a variety of graphical displays in addition to text
- Improved video export system, including the following changes:
  - o Export process runs within ICON
  - o Video export will pause automatically while video is being recorded.
  - o Improved performance and stability.
- Rotational control templates for actuators and tracks.

# Additional Changes and Bugfixes

- ICON RPT has been removed.
- Video display system overhauled to improve performance.
- The options available in the group preferences section have been moved to system preferences.
- Miscellaneous bugfixes and performance improvements increasing the stability of the application.

## Known Issues, Limitations, and Restrictions

• Some application settings and preferences will be reset to their default values.



### **Patches**

#### 4.6.1

- Changed snapshot export format to TIFF from PNG.
- Resolved some issues related to the video export system.
- Resolved some communication issues.
- Added support for broadcast stopping devices.
- Additional minor bugfixes.

# System Requirements

- Supported operating systems: Windows™ 10 (Professional recommended)
- Processor: Sixth generation Intel® Core i5 or greater
- **Graphics:** Intel® UHD 620 or greater with Intel® Quick Sync enabled, DirectX 11 or higher compatible
- Memory: 8 GB
- Minimum available disk space: 500 GB
- Minimum resolution: 1920 × 1080 pixels