Eddyfi Technologies
Beyond current

MAGNIFI 5.0
EXISTING CLIENT UNDER VALID MAINTENANCE PLAN

© 2022 Eddyfi Technologies

New cloud-based licensing

- ✓ No more Hardware keys & Software keys
- ✓ Activated in seconds
- ✓ Easily deactivated/reactivated to facilitate sharing
- ✓ Internet required on initial activation, but remains valid when connection is lost



Activation of STD and PRO licenses with HK

Activation of your current STD or PRO license

MAGNIFI 4.X USERS WITH A HARDWARE KEY (HK)

<u>Your current HK number = required *License code* to access 5.0</u>

1. Make sure your computer is connected to the internet.
2. Connect your hardware license key (Magnifi 4.x) to your computer.
3. Start Magnifi 5.0
4. License Validation Failure window will automatically open.
5. Click on *Manage*



Activation of your current STD or PRO license

MAGNIFI 4.X USERS WITH A HARDWARE KEY (HK)

1. Enter the same number as your 4.X key (software or hardware).
2. Click Refresh and Activate.





Activation of STD and PRO licenses with SK

Activation of your current STD or PRO license

MAGNIFI 4.X USERS WITH A SOFTWARE KEY (SW)

<u>Your current HK number = required *License code* to access 5.0</u>

1. Retrieve your license key number from the current 4.X version you are using.
    1. Backstage
    2. Help menu
    3. *Manage…* icon
    4. *Software* tab
2. Write down the *License ID* number



Activation of your current STD or PRO license

MAGNIFI 4.X USERS WITH A SOFTWARE KEY (SW)

<u>Your current HK number = required *License code* to access 5.0</u>

1. Make sure your computer is connected to the internet.
2. Connect your hardware license key (Magnifi 4.x) to your computer.
3. Start Magnifi 5.0
4. License Validation Failure window will automatically open.
5. Click on *Manage*



Activation of your current STD or PRO license

MAGNIFI 4.X USERS WITH A HARDWARE KEY (HK)

1. Enter the same number as your 4.X key (software or hardware).
2. Click Refresh and Activate.

A1a2bb344- …



Use the ACQ license

Use Magnifi with ACQ license

CHANGE LICENSE KEY NUMBER TO CHANGE ACCESSIBLE FEATURES

ACQ license code = MAG4.X license code + “-A”

1. Access the *Manage License* window:
   1. *License* menu in Backstage
   2. *Manage…* button
2. Click on *Release*. *License Code* field becomes editable.
3. Add “-A” at the end of the *License Code* displayed in the field.
4. Click Refresh and Activate.

+ “-A” = 1113338888-A

or

A1a2bb344- … **+ “-A”** = …GF43b-A



Use TubePro

Use TubePro license

ACCESS TUBEPRO FOR ASSOCIATED KEYS TO MAGNIFI

TubePro license code = MAG4.X license code + “-T”

1. Download and install TubePro 5.6: https://eddyfi.com/en/software/eddyfi-tubepro
2. Start TubePro.
3. License Validation Failure window will automatically open.
4. Click on *Manage*
5. Enter your license code
6. Click Refresh and Activate.



+ “-T” = 1113338888-T