



Magnifi GO 1.3R11 Release Notes

System Requirements

- Reddy® instrument (32, 64, 128 channels)

New Features and Improvements

Surface ECA Features

- Support for I-Flex™ probe
- Support for more than one topology in same setup file using configuration wizard (e.g., impedance and short, double driver).
 - When a topology is selected all the groups in the topology are automatically selected.
 - Users can manually remove a topology group.
 - Select a group from one topology and another from a different topology.
- Feature limited by the instrument's channel capabilities.

Modifications to Existing Features

Surface ECA Features

None in this version.

Dropped Features

Surface ECA Features

None in this version.

Resolved Issues

Surface ECA Features

- Report files did not have .pdf, .xls, .doc file extensions
- Reddy® data transfer not properly working with an external drive
- C-scan view cursor automatically adjusted size when stopping acquisition
- 2D median filter not correctly applied to C-scan display
- 2D real-time C-scan processing introduced glitches in display
- Auto-calibration shortcut unavailable in Sharck™ setup file on Reddy
- Sharck pencil probe setup not in default master list
- Sharck pencil probe setup with inappropriate filtering



Known Issues, Limitations, and Restrictions

Surface ECA Features

- Automatic calibration not working on C-scan data
Workaround
Calibrate manually.