

Magnifi GO 1.4R10 Release Notes

System Requirements

- Reddy® instrument (32, 64, 128 channels)
- Reddy® AC-E instrument

Firmware

Included in this release of Magnifi GO are the following firmware:

Reddy®

- Version: 2.0R8

Reddy® AC-E

- Version: 2.0R8

New Features and Improvements

- None in this version.

Modifications to Existing Features

- None in this version.

Dropped Features

- None in this version.

Resolved Issues

- Eddyfi logo updated
- In acquisition mode, the C-Scan display was crashing when the scan was reaching the filled scan distance limit on Windows 10
- User was not able to add an indication when the data file was recorded with a negative offset
- Defect indications were not displayed on Code and Strip Chart views
- Opening SHARCK-BW053-G2 file caused permanent warning in the Calculated Information Fields

- Spikes data appeared when activating the persistence mode on the Reddy AC-E

Known Issues, Limitations, and Restrictions

- General lift-off compensation for ECA probes possible if process added in advanced mode.
- Record button not enabled when auto-recording if off
- Resizing cursor in Strip Chart using keypad is not refreshing data in Lissajou